

MECHANICAL KEYBOARD FIGHTER 2 VMK88B

Package Contents


1. Mechanical keyboard
2. User manual

Mechanical Keyboard Characteristics

- * Material: ABS
- * XINDA blue pluggable switches
- * Chip; SX83099
- * 104 keys with double injection
- * 26 keys with anti-ghosting
- * 6 colors of LED light, 12 kinds of lighting modes
- * USB PVC cable
- * Plug and play
- * Dimension: 445*155*38.5mm
- * Compatible with Windows XP, Vista, Win7/8/10, Linux, Mac & Mac

Keyboard Functional Introduction

* 26 keys anti-ghosting: Q, W, E, R, T, A, S, D, F, G, Z, X, C, V, B, M, TAB, CapsLock, Shift_L, Ctrl_L, Alt_L, Space, ↑, ↓, ←, →

* Keyboard backlight adjustment button , total 12 LED modes:

Backlight mode 1	Snake-shaped running horse
Backlight mode 2	wave
Backlight mode 3	Vertical, row by row
Backlight mode 4	Horizontal, line by line
Backlight mode 5	Leaning transformation
Backlight mode 6	Cross lighting
Backlight mode 7	Single Light
Backlight mode 8	Left and right scan
Backlight mode 9	Longitudinal brightening and fading
Backlight mode 10	Dot spread
Backlight mode 11	breathing
Backlight mode 12	Lighting fixed

* Keyboard backlight brightness adjustment:

Fn + ↑: Increase the brightness of the backlight; 4 gears;

Fn + ↓: Decrease the brightness of the backlight; 4 gears;

* Keyboard backlight running/breathing frequency adjustment:

Fn + ←: Decrease backlight running/breathing frequency; 3 gears;

Fn + →: Increase backlight running/breathing frequency; 3 gears;

* Fn + Win _ L: locks Win and APP keys and has a light indicating the current state;

* Fn +[F1 ~ F12]: Implement multimedia functions

	Key combination	Implementation function	Key combination	Implementation function
Fn+	F1	Media	F7	Play/Pause
	F2	Volume-	F8	Next Track
	F3	Volume+	F9	Email
	F4	Mute	F10	Web/Home
	F5	Stop	F11	----
	F6	Pre-track	F12	Calculator

Safety Instructions

1. Keep the keyboard away from sharp objects that could damage it.
2. Do not put heavy objects on the keyboard.
3. Do not stretch, twist or apply force to the keyboard.
4. To clean the keyboard, gently wipe it using a moist cotton cloth.
5. Make sure the keyboard is turned off before cleaning. Do not use liquid cleanser.

KLAWIATURA MECHANICZNA FIGHTER 2 VMK88B

Zawartość opakowania

1. Klawiatura mechaniczna, 2. Instrukcja obsługi

Specyfikacja techniczna:

- * Obudowa: ABS
- * Przetaczniki: wymienne, XINDA Blue
- * Chip: SX83099
- * 104 klawisze z podwójnym formowaniem wtryskowym
- * 26 klawiszy z systemem anti-ghosting
- * 6 kolorów podświetlenia
- * 12 trybów podświetlenia
- * Kabel USB PVC
- * Plug and play
- * Wymiary: 445*155*38.5mm
- * Kompatybilność: Windows XP, Vista, Win7/8/10, Linux i Mac

Funkcje klawiatury

* 26 klawiszy z funkcją anti-ghosting: Q, W, E, R, T, A, S, D, F, G, Z, X, C, V, B, M, TAB, CapsLock, Shift_L, Ctrl_L, Alt_L, Space, ↑, ↓, ←, →

* Aby zmieniać ustawienia podświetlenia należy wcisnąć przycisk



Podświetlenie 1	Snake
Podświetlenie 2	Disco
Podświetlenie 3	Poziomo, linia po linii
Podświetlenie 4	Pionowo, rząd po rzędzie
Podświetlenie 5	Mix
Podświetlenie 6	Mix 2
Podświetlenie 7	Brak podświetlenia
Podświetlenie 8	Poruszający się wzór
Podświetlenie 9	Fala
Podświetlenie 10	Podświetlenie po wciśnięciu przycisku
Podświetlenie 11	Pulsujące podświetlenie
Podświetlenie 12	Stałe podświetlenie

* Regulacja jasności podświetlenia:

Fn + ↑: Zwiększa jasność podświetlenia; 4 stopnie

Fn + ↓: Zmniejsza jasność podświetlenia; 4 stopnie

* Regulacja częstotliwości zmiany wzoru:

Fn + ←: Zmniejsza częstotliwość zmiany wzoru; 3 stopnie

Fn + →: Zwiększa częstotliwość zmiany wzoru; 3 stopnie

* Fn + Win + L: blokuje funkcjonalność klawisza Windows

* Fn + [F1 ~ F12]: Aktywacja funkcji multimedialnych

	Kombinacja	Funkcja	Kombinacja	Funkcja
Fn+	F1	Odtwarzacz multimedialny	F7	Odtwarzaj / Pauza
	F2	Głośność -	F8	Następny utwór
	F3	Głośność +	F9	E-mail
	F4	Wycisz	F10	Przeglądarka internetowa
	F5	Stop	F11	----
	F6	Poprzedni utwór	F12	Kalkulator

Instrukcje bezpieczeństwa

1. Trzymaj klawiaturę z dala od ostrych przedmiotów, które mogłyby ją uszkodzić.
2. Nie kładź ciężkich przedmiotów na klawiaturze.
3. Nie naciągaj, nie skracaj ani nie używaj siły korzystając z klawiatury.
4. Aby wyczyścić klawiaturę, delikatnie przetrzyj ją wilgotną bawełnianą szmatką.
5. Upewnij się, że klawiatura jest wyłączona przed czyszczeniem. Nie używaj płynnego środka czyszczącego.