

TM-058无线插卡头戴耳机

按键操作说明：

1- POWER/PLAY:

长按3秒为开关机

无线来电状态,短按接听来电、长按拒听,连续按两下为重拨

无线播放状态短按播放、暂停

TF卡播放状态短按播放、暂停

FM状态短按自动搜索电台

2- PREV/VOL-:

无线状态时短按上一曲、长按音量减

MP3状态时短按上一曲、长按音量减

FM状态短按上一个频点、长按音量减

3- NEXT/VOL+:

无线状态时短按下一曲、长按音量加

MP3状态时短按下一曲、长按音量加

FM状态短按下一个频点、长按音量加

4- MODE:

短按模式转换,无线/MP3/FM

指示灯：

无线状态：配对状态蓝红灯快闪,配对成功后蓝灯慢闪

MP3状态：播放时蓝灯慢闪

FM状态：收音电台时蓝灯慢闪

充电状态：充电时红灯长亮,充电完成后红灯灭

无线使用操作说明：

1- 长按POWER键3秒开机,开机默认无线状态

2- 蓝红灯快闪,无线进入配对状态

3- 用手机搜索本产品无线,无线名称为TM-058

4- 当手机搜索到TM-058设备名称时点连接,如果提示输入密码,密码为0000

5- 当无线连接成功后,蓝灯慢闪

6- 打开手机音乐播放器就可以播放音乐,本产品可以控制无线上下曲及播放暂停及通话接听,重拨等功能

MP3使用操作说明：

1- 长按POWER键3秒开机

2- 插入TF内存卡即进入MP3歌曲播放状态或短按MODE键转到MP3播放状态

3- 短按PLAY键为MP3播放/暂停

4- 短按NEXT或PREV为MP3上下曲控制

5- 长按NEXT或PREV为MP3音量大小控制

FM使用操作说明：

1- 长按POWER键3秒开机

2- 短按MODE键到FM模式

3- FM状态短按PLAY键为自动一次性搜索全部能收到的电台

4- 短按NEXT或PREV为选择已经搜索到地电台

5- 长按NEXT或PREV为FM音量大小控制

LINE 外接音频输入操作说明：

1- 开机状态,插入音频线转到AUX LINE IN模式

2- 支持手机/iPod/MP4/MP3/CD/笔记本等外接音频输入

功能参数：

USB充电：DC 5V IN

FM频率：87.5-108MHz

无线频率：2.401-2.480GHz

无线距离：10米

频响：20HZ-20KHz

输出功率：35mW

信噪比：88Db

充电时间：2小时内

TM-058 WIRELESS HEADPHONE

Key Operating Instructions:

1. POWER/PLAY

Turn on/off key, Long press three seconds is power on/off

In Wireless mode when get the calling: Short Press is answer the calls; Long Press is Refuse to listen, continuous push 2 times is redial

In Wireless mode, Short Press: play/pause;

In MP3 mode, Short Press: Play/Pause

In FM mode, Short Press: Automatic searching the broadcasting station.

2. -PREV/VOL-

In Wireless mode, Short Press: Previous; Long Press: volume-

In MP3 Mode, Short Press: Previous; Long Press: volume-

In FM mode, Short Press: Previous a frequency; Long Press: volume-

3. +NEXT/VOL+:

In Wireless mode, Short Press: next; Long Press: volume+

In MP3 mode, Short Press: next; Long Press: volume+

In FM mode, Short Press: next frequency; Long Press: volume+

4. MODE:

Short Press to change the mode, Wireless/MP3/FM Radio/AUX LINE IN;

LED Indicator:

In Wireless mode, the blue/red light will be twinkle flash, when the headphone matches the phone successfully, the blue light will slow flashing when connection successful.

In MP3 mode, the blue light will slow flashing when playing;

In FM mode, the blue light is on steadily when hearing the FM radio, the light twinkles fast when searching the FM radio

In charging mode: the red light is on steadily when charging, when it's fully charged, the red light will be off.

Wireless using the operating manual:

1. Long Press the power key three seconds to open the power, it is Wireless of the default open

2. The blue/red light twinkles fast, Wireless into pairs.

3. When your mobile phone searches the Wireless product, the Wireless name is TM-058

4. When your mobile phone searches the Wireless product and connects successfully, if it displays

need put into the password, the password is 0000

5. The blue light will continuous flash 2 times on each 5 seconds after Wireless connects

successfully

6. When you open your mobile phone of music player, you can listen to the music, this product can

control the next song and previous song by Wireless, play and pause, answer the phone and redial,

etc.

MP3 Operating Instructions

1. Long Press power key three seconds to open the power;

2. Insert TF card that the MP3 will play automatically. Or long press the mode key and will switch to

MP3 mode.

3. Short press the Play key: MP3 play/pause;

4. Short Press Next/Previous : next/previous song

5. Long Press Next/previous: Volume+/-

FM Operating Instructions

1. Long Press power key three seconds to open the power;

2. Short Press Mode key to FM Mode;

3. In FM mode, short press the Play key is automatic searching all the frequency.

4. Short Press Next or Previous; select the frequency that has been searched.

5. Long Press Next or Previous: Volume+/-

LINE Connecting To Audio Jacke:

1. Power on mode, insert the Auxio cable will turn to AUX LINE IN mode.

2. Support mobile phone/iPod/MP4/MP3/CD/PC, etc

Functional Parameter:

USB charge : DC 5V IN

FM frequency : 87.5-108MHz

Wireless frequency : 2.401-2.480GHz

Wireless distance: 10 meters

Frequency : 20Hz-20KHz

Output power: 35mW

SNR : 88dB

Charging time : ≤2 hours