


**Double 8" Active Speaker Box
With LED Disco Light**

Model:MS-20282DA
User's User Manual



Thank you for choosing our product. We hope you enjoy each and every use of this product. We suggest that you read this user manual carefully before primary use in order to utilize all of the features in functions installed. Please store it in a safe place for future reference and pass in on to the next owner.

Caution & Safety Guide:

- *Please power off the unit when not in use. If the unit will not be in use for extended periods, it is suggested that you disconnect the unit from its power source.
- *To prevent damage to the unit do not install in areas of extreme heat or in areas with direct exposure to sunlight.
- *Do not install the unit in or near a place where it may come in contact with rain, moisture or other liquids.
- *To clean the unit, simply wipe it down using a dry, soft cloth. The unit should never be cleaned chemicals or detergent.
- *In the near occurrence of malfunction do not attempt to repair the unit on your own. Contact a certified service professional for a proper diagnosis and repair.

Caution: Dismantling the unit on your own is dangerous and may cause damage to your person or property and will void the warranty.

CONTROLS

1. MP3 PLAY

2. SD Port

To Insert SD Card for MP3 Files.

3. USB Port

To Insert USB memory for MP3 Files.

4. Power indicator

GREEN LED- ON

CHARGE- red LED light on (Low battery, red LED will be flash)

FULL- Blue LED light on

5. MICROPHONE INPUT 1 : Connector for a balanced microphone.

6. MICROPHONE INPUT 2 : Connector for a balanced microphone.

7. AUX INPUT

Allows cassette recorder or CD player to the Main output.

8. DC IN 15V

9. MICROPHONE VOLUME LEVEL

Allows you to increase or decrease the volume level.

10. ECHO

Allows you to increase or decrease the ECHO level

11. TREBLE

This knob adjusts terble

12. BASS



This knob adjusts bass

13. VOLUME

Allows you to increase or decrease the volume level.

14. Power Supply Switch.

15. LED Switch.



Once again we thank you for purchasing the Speaker.

We hope that you enjoy this product every time it is put to use and therefore, we suggest that you keep this user manual safe for future reference and so it may be passed on to the next owner.

Enjoy!