




























SUZUKA

GAMING CHAIR

USER MANUAL VGSCZ

Ax1 	Ix16  M8x20	Qx1 	① 	② 	③ 
Bx1 	Jx10  M6x16				
Cx1 	Kx2  M5x8				
Dx5 	Lx2 		③ 	④ 	⑤ 
Ex1 	Mx1 				
Fx1 	Nx1 				
Gx1 	Ox1 		⑥ 	⑦ 	⑧ 
Hx1 	Px5 